

Protect Your Collection System

With Rhino's Damage Prevention Tools

Part # RHD-44A

Hybrid Post Driver

- Used to install all Rhino Hybrid posts
- Turn upside down and insert flat post, pointed end out
- Flip back over and drive up and down until burial depth is reached



RhinoMarkers.com

| 800.522.4343